

DUROFEL® XF

Basic durometer for soft fruits and vegetables

Agrosta

Many thanks for having acquired a Durofel XF

This instrument gives the Durofel Index when you press the tip on a sample till the plastic abutment

You should obtain 100% when you press hardly on a table or hard flat surface

If it is not the case, the instrument has to be calibrated

Your box contains :

- The instrument pre-equipped with a 9V battery
- A certificate of conformity

Push on the button, the device is ready to measure :



TAKE CARE : WHEN YOU SWITCH ON THE INSTRUMENT, THE SENSOR TAKES ITS ORIGIN – SO TAKE THE SENSOR IN YOUR HAND IN WORK POSITION WHILE YOU START THE DEVICE

You are ready to measure : take your samples one after each other, and press till plastic abutment – You obtain instantly the firmness :



To change the battery :

